

LAMINATE

Laminate flooring is naturally durable and stain resistant. Its unique grain and color are integral components of its beauty. Follow these simple care instructions to maintain your floor's appearance for many years to come.

MAINTENANCE & CARE

- Sweep or vacuum regularly to remove loose dirt.
- Use a vacuum with a hardwood floor attachment or one in which the beater bar can be turned off to avoid scratching the floor.
- Laminate flooring must not be exposed to excessive moisture or dryness. Maintain humidity levels and do not oversaturate when cleaning.
- Using a proper laminate floor cleaner, spray lightly on a dust mop, and mop back and forth lengthwise along floorboards. We recommend Bona Laminate Floor Cleaner, available at FLOOR360.

PREVENTATIVE MEASURES

- Place non-staining mats or area rugs at all exterior entrances to prevent dirt and soil from being tracked onto your floor. Be certain to clean those mats often so they keep the outside from coming in.
- Protect flooring by installing felt runners under furniture or chair legs to avoid scratches when they are moved. When moving furniture, lift to avoid scratching the floor.
- Use a damp white cloth to blot up spills promptly.
- Maintain a consistent indoor humidity level.

CLEANING

- For routine cleaning, see the Maintenance & Care section at the top of this care sheet.
- Do not oversaturate when cleaning.
- Do not wet-mop the floor with soap, water, oil-based soap, detergent, or any other liquid cleaning solution. This may cause swelling, warping, or delamination and will void your product warranty.
- Do not use steel wool, abrasive cleaners, ammonia or chlorine based cleaners. Do not use any type of buffing or polishing machine on your laminate flooring.
- For tough stains or spills, information is available at your product manufacturer's website. Contact FLOOR360 for additional assistance.

Did you know?

Humidity levels in the home should be maintained between 35% and 45% by using a humidifier or dehumidifier as needed.

FLOOR360

FLOOR360.COM service@floor360.com

MADISON 5117 Verona Rd • 608 274-2500

MILWAUKEE 12500 W Silver Spring Dr • 262 646-7811